

Date	Prepared by	Approved by	Document nos	Revision
19 May 2020	Ray Ling	Pavel Lagoiski	MS-6.3-IM-001	1

Applicable Model: MS-6.3DB90, MS-6.3DB90-T**TABLE OF CONTENTS:****1.00 BEAMS & CONNECTORS:**

- 1.10 Plan View Resultant Beam And Connector Layout
- 1.20 Connector Detail
- 1.30 Connector Ports Table

2.00 PATTERN DIAGRAM

- 2.10 High Band
 - 2.11 MS-6.3DB90 (Frequency: 1695 - 2690 MHz)
 - 2.12 MS-6.3DB90-T (Frequency: 1695 - 2690 MHz)
- 2.20 Low Band
 - 2.21 MS-6.3DB90 (Frequency: 698 - 960 MHz)
- 2.30 T Band
 - 2.31 MS-6.3DB90-T (Frequency: 617 - 896 MHz)

3.00 MANUAL TILT ADJUSTMENT**4.00 RET ACTUATOR INSTALLATIONS (Optional)**

- 4.10 Installation Process (Reverse Process for Uninstallation)
- 4.20 RET Actuator kit and tools

5.00 TRANSPORTATION / INSTALLATION


- 5.10 Transportation (From Point to Point)
- 5.20 Bracket Mounting
- 5.30 Installation using a crane
 - 5.31 Lifting the Antenna
- 5.40 Antenna Installation
 - 5.41 Antenna Levelling
 - 5.42 Digital Level Gauge Calibration
 - 5.43 Adjustment Requirement

Revision History:


Date	Description	Revised by	Revision nos.
19-May-20	To include MS-6.3DB90-T and update all to newest requirement.	Ray Ling	1

1.00 BEAMS & CONNECTORS:

1.10 Plan View Resultant Beam And Connector Layout



1.20 Connector Detail



1.30 Connector Ports Table


Low Band or T-Band	BEAM 3		BEAM 2		BEAM 1	
	Port 18 (-45°)	Port 17 (+45°)	Port 16 (-45°)	Port 15 (+45°)	Port 14 (-45°)	Port 13 (+45°)
High Band	BEAM 6	BEAM 5	BEAM 4	BEAM 3	BEAM 2	BEAM 1
	Port 12 (-45°)	Port 11 (+45°)	Port 10 (-45°)	Port 9 (+45°)	Port 8 (-45°)	Port 7 (+45°)

2.00 PATTERN DIAGRAM

2.10 High Band

2.11 MS-6.3DB90 (Frequency: 1695 - 2690 MHz)

2.12 MS-6.3DB90-T (Frequency: 1695 - 2690 MHz)




2.20 Low Band

2.21 MS-6.3DB90 (Frequency: 698 - 960 MHz)

2.30 T Band

2.31 MS-6.3DB90-T (Frequency: 617 - 896 MHz)




3.00 MANUAL TILT ADJUSTMENT

Step 1: Tilt Stopper Loosening.





Step 2: Adjusting the Tilt.

Step 3: Tilt Stopper Tightening.



4.00 RET ACTUATOR INSTALLATIONS (Optional)


4.10 Installation Process (Reverse Process for Uninstallation)



Step 7: Screw and tighten RET cable



Step 8: RET Actuator installation complete.



4.20 RET Actuator kit and tools

RET Attachment Interface (Sub-Assy)




RET Attachment Interface (Sub-Assy)

RET Attachment Interface Kits




Shaft Stopper



Hex Adaptor



Shaft Handle



RET Actuator




RET cable



5.00 TRANSPORTATION / INSTALLATION


5.10 Transportation (From Point to Point)

Strictly comply to the Local authority and regulatory on Workplace Safety and Health Control and Measure when moving and transportation of large or heavy equipment, appropriate material handling machine should be use. **(Risk Assessment apply for Forklift or Pallet Truck Lifting)**



5.20 Bracket Mounting

Lens Size (Model)	Bracket Qty (pc)	Bolt & Nuts Size	Bolts Set (pc)
MS-XXX180 Lens	6	M14 x 15cm	12
MS-XXXX 60,90,120 Lens	4	M12 x 15cm	8



Tighten to the pole with Bolt & Nuts Sets

Important Notes:
End User is require to Custom-Make the additional supporting bracket and tighten to the existing Antenna bracket to meet the deployment needs.

5.30 Installation using a crane

Strictly comply to the Local authority and regulatory on Workplace Safety and Health Control and Measure when performing lifting of large or heavy equipment, appropriate material handling machine should be use and only certified personal should perform the task. **(Risk Assessment require to apply for both Up-Lifting and Down-Lifting.)**

5.31 Lifting the Antenna

The antenna has 2 hook points installed on the top frame (located slightly behind the center of the sphere). These hooks are designed at the center of gravity point of the antenna. A cable, rope can be securely fastened to the hooks and the antenna can be lifted using a crane or forklift as pictured below.




5.40 Antenna Installation

With reference to "**Bracket Mounting**" Procedure, End user is required to Custom-Make the additional supporting bracket and tighten it to the existing Antenna bracket to meet the deployment needs.

5.41 Antenna Levelling

After the Antenna is mounted to the bracket, it is required to be adjusted to 0° (Zero Degree) with $\leq 0.2^\circ$ on 3 sides of the frame top level. (Rear, Right & Left=As shown in picture)



ANTENNA LEVELING ADJUSTMENT (AFTER INSTALLATION)

5.42 Digital Level Gauge Calibration



5.43 Adjustment Requirement

